


WE GIVE YOU THE SECURITY YOU NEED

Factory calibration - solid reliability!

- > Indirect traceability to the national standard
- > Factory calibration according to the standard DIN EN ISO 6789:2003
- > Factory calibration if necessary with adjustments and repairs - for GEDORE products only
- > Factory test certificate and calibration stamp

Factory test certificate according to DIN EN ISO 6789:2003

- > It contains information about the test item, measurement results, the test equipment used and the classification of the test item according to DIN EN ISO 6789:2003 (e.g. Type II Class A).
- > The calibration is carried out on test equipment, which comply with the DIN EN ISO 6789:2003.
- > The calibration result of the factory certificate does not take consideration of any measurement inaccuracies by test equipment at individual hierarchy steps.
- > The documented measuring inaccuracies refers only to the test item.



Factory Calibration



Note

Calibration always represents a snapshot! Within the framework of calibration, deviations in measurements and measurement inaccuracies are recorded on a certain date and documented accordingly in the calibration certificate. Using these calibration results, a statement can be made as regards tolerance accuracy since the previous calibration. No statement can however be made as regards future performance.

If you have any queries, simply call our service hotline:


+49 (0) 1804 37 36 68

The generation of a factory test certificate in accordance with GEDORE criteria as well as adjustment and repair is exclusively possible for torque wrenches and test equipment manufactured by us.

Factory and DAkkS calibrations involve right calibration. Left calibration also available on request.

Depending on the requirements or customer requests, we calibrate in accordance with DAkkS guidelines or GEDORE criteria

DAKKS CALIBRATION - 100 % DOCUMENTED SAFETY



- Direct traceability to the national standard
- DAkkS calibrations to DAkkS Guidelines: DAkkS-DKD-R 3-7:2003; DAkkS-DKD-R 3-8:2003 and DIN EN ISO 6789:2003
- Minimum measurement inaccuracies
- DAkkS calibration of our own products and those of other manufacturers
- Air-conditioned laboratory controls under the most stringent conditions
- DAkkS calibration certificate and DAkkS calibration stamp

DAkkS Calibration

Test subject	Test device	Test result
Mech. torque wrench 0,2-1.000 N·m	PTB 1%	DAkkS DIN EN ISO 6789
Electr. torque wrench 0,2-3.000 N·m	PTB 0,2%	DAkkS DAkkS-R 3-7
Torque testers 0,2-3.000 N·m	PTB 0,2%	DAkkS DAkkS-R 3-8

Example

A torque wrench is calibrated in accordance with DIN EN ISO 6789:2003. Calibration is performed on test equipment approved by DAkkS.

Depending on the design and type, the torque wrench is calibrated at +/- 4% or +/- 6%. In addition to measurement deviations, measurement inaccuracy is also documented in the DAkkS calibration certificate.

The torque wrench can be used in accordance with the applicable DIN EN ISO standards.

DAkkS calibration equipment

We calibrate your test equipment or torque wrenches on DAkkS-calibrated reference wrenches or test equipment. DAkkS calibrations of test equipment are performed regularly by PTB and/or Schatz. This fact ensures that the maximum possible accuracies and minimum possible measurement inaccuracies are provided. Before each calibration process, a preliminary test is performed in our DAkkS laboratory on each item of calibration equipment and on each reference wrench.


International recognition

The DAkkS calibration certificate and therefore the measurement results listed are recognised in many other countries as official evidence of traceability. This is based on multilateral treaties.

DAkkS calibration certificate

The DAkkS calibration certificate documents the calibration result - the DAkkS calibration mark on the test item identifies the DAkkS laboratory performing calibration. Please note our registration number: DAkkS-K-28201. During the test process, the Richard Abr. Herder GmbH & Co. KG calibration laboratory is obliged to comply with the contractual criteria of the DAkkS (formerly DKD). Apart from the standard test certificate contents, the DAkkS calibration certificate also takes consideration of the measurement inaccuracies of the test equipment used. The documented calibration result includes the measuring inaccuracies of both the test item and the test equipment. DAkkS calibration therefore represents maximum safety for controlled tightening. We advise using it for larger test items or test equipment subject to continuous use.
Für größere Prüfstände oder Prüfgeräte im Dauerbetrieb ratsam.





OUR SERVICE - QUALIFIED AND CUSTOMISED

Our reasonably-priced factory calibration service fulfills the requirements according to DIN EN ISO 6789. Our proprietary accredited DAkkS calibration laboratory creates certificates in accordance with the applicable standards and requirements as per DAkkS 3-7 and DAkkS 3-8 as well as DIN EN ISO 6789:2003.

Our repair service will repair your GEDORE torque wrenches within 5-7 working days.

Please note that the torque wrench is an item of measuring equipment.

We recommend

- Calibration once a year (DIN EN ISO 6789:2003)
- or after 5000 load cycles (DIN EN ISO 6789:2003)

Your advantage

- Torque wrench offering measurement accuracy
- Free* calibration service at Torque Tech GmbH & Co. KG

*Only applies for mechanical items supplied by us (RAHSOL/GEDORE)
Full service package / services only apply for Germany. Please enquire in our subsidiaries about the possibilities for your respective country.



Regular calibration, adjustment and certification. Why is this so important?

- Only then can we guarantee the precision and reliability of our torque tools over the long term. We attach a great deal of importance to this as your safety is something which is close to our heart.
- Because we offer you the safety you require for everyday "controlled tightening".

GEDORE - competent control of the highest level


HEALTH IS THE MOST IMPORTANT FACTOR WHEN IT COMES TO LIVING A HAPPY LIFE.

To ensure that you use our tools safely, please observe the following information.*

Why should heavy tools be stored in the bottom?

- Always store the heaviest tools in the bottom (heavy-duty) drawer.
- When the bottom drawer is opened, the centre of gravity is relocated to a safe range.
- Storing heavy tools in the upper drawers relocates the centre of gravity upwards.
- When the drawer is opened, the centre of gravity is relocated to a critical range.
- This makes the tool trolley very susceptible to lateral forces. If the trolley is exposed to lateral forces such as impact, it can overturn.
- Always observe the load capacity for each drawer to ensure that you always stay in the safe range.

- S 1 = tool trolley centre of gravity when the drawer is closed
- S 2 = tool trolley centre of gravity when the drawer is opened
- red = critical range - danger of overturning



i General

- Always wear safety goggles for tasks involving chips or the possibility of parts splintering.
- Only use the hand tools for their intended purpose.
- Never modify or tamper with tools. Exceptions: Professional regrinding of chisels, scrapers, cutting tools as well as hammer edges.
- Never work with damaged tools. Damaged tools must be replaced immediately.
- Handles must be free of oil and grease.
- Depending on the task, protect your hands by wearing work gloves.
- Work on live circuits may only be performed by qualified personnel using suitable VDE tools.
- Choose a safe surface to ensure stability. Wear safety shoes.
- Wear the specified ear protection when working in noisy environments.



Tool trolley

- Lesen Sie die Betriebsanleitung!
- Öffnen Sie immer nur eine Schublade! Beim gleichzeitigen Öffnen mehrerer Schubladen erhöht sich das Kippmoment und der Werkzeugwagen kann umkippen.
- Bewahren Sie die schwersten Werkzeuge immer in der unteren (Schwerlast-)Schublade auf. Eine Lagerung in den oberen Schubladen verlagert den Schwerpunkt nach oben und das Kippmoment steigt. Der Werkzeugwagen kann umkippen.
- Beachten Sie die zulässige Tragkraft der einzelnen Schubladen und die Gesamttragkraft des Werkzeugwagens!
- Bewegen Sie den Werkzeugwagen nur mit geschlossenen und verriegelten Schubladen! Achten Sie dabei auf nicht gesicherte, lose auf der Ablage oder Arbeitsfläche liegende Gegenstände!
- Stellen Sie den Totalfeststeller beim „Parken“ des Werkzeugwagens immer fest! Nur so ist der Werkzeugwagen vor unbeabsichtigten Bewegungen gesichert!
- Auf Steigungen den Werkzeugwagen immer „bergwärts“ fahren!
- Benutzen Sie den Werkzeugwagen nicht als Leiterersatz!
- Spitz oder scharfe Gegenstände niemals ungesichert im Werkzeugwagen aufzubewahren! Reißnadeln lassen sich z. B. durch Aufstecken eines Korkens entschärfen.



Tool chests

- Do not use the tool chest for climbing.
- Never store pointed or sharp items loosely in the tool chest. Scribers can be made safe by sticking them in a cork, for example.
- Take care of your back by going down on your hunkers and keeping your upper body straight when lifting out the tool box.



Spanners

- Only use spanner sizes and profiles which fit the bolt or nut head.
- Do not use spanners as levers or as striking tools.
- Select the spanner in accordance with the screwed connection. This particularly applies to screwed connections with high torques.
- Never extend the tool lever arm except when the tools are designed especially for this purpose, e.g. single-ended ring spanners.
- Never hit a spanner with a hammer except when the tools have an area designed especially for this purpose, e.g. slogging spanners.
- Always apply the spanner at a right angle to the bolt axis.
- Always pull the spanner towards you. Never push the spanner away from you. If for design reasons you can only press the spanner away from you, use your open hand to prevent injuring your knuckles.
- Ring spanners transmit the forces more consistently. Ring spanners are therefore more suitable for large torques.
- Apply open-ended spanners in such a way that the angle of the jaw is facing in the direction of rotation.
- If a torque is specified for the screwed connection, use a torque wrench.
- Never work with damaged spanners. Do not repair damaged spanners but rather replace them without delay.

* Furthermore, the relevant safety guidelines of various institutions apply, e.g. the guidelines of the trade associations, employers' instructions and the statutory specifications of the respective country.





Screwdrivers

- › Choose the screwdriver which is suitable for the respective bolt head profile.
- › Place the workpiece on a ledge or clamp it. This helps to avoid injuries incurred by sliding blades.
- › Avoid cuts by directing the requisite pressure for releasing or tightening the bolt head away from your body.
- › Wear protective gloves when working with screwdrivers.
- › If the screwdriver is too long, do not under any circumstances shorten the blade or handle. Choose a shorter screwdriver.
- › Do not use the screwdriver as a caulking or crushing tool.
- › Light hammer impact may only be applied for loosening screws using suitable screwdrivers with striking cap or continuous blade.
- › If the bolt fails to loosen, use the GEDORE impact driver set no. K 1900-013 to release the bolt without destroying it.
- › Insulated and tested screwdrivers must be used when working on electrical systems.



VDE tools

- › Work on electrically live equipment may only be carried out by trained electricians.
- › Only tools and safety equipment marked with the double triangle or bell 1000 V symbol (refer to BGV A3) may be used.
- › Before commencing any work, check the insulation for damage.
- › Damaged tools must not be used.
- › The regulations of the employers' liability insurance associations and power supply companies must be complied with.
- › GEDORE VDE tools are approved for work on live circuits at voltages up to 1000 V AC and 1500 V DC.
- › Tools must not be combined unless they are designed to be securely joined together.




Ratchets, tools and sockets

- › Ratchets are suitable for swift releasing and tightening.
- › Avoid jerky movements with the ratchet, e.g. caused by hammer impact.
- › The square drive and the tool and socket square drive must be of the same size.
- › Select the drive size in accordance with the screwed connection. This particularly applies to screwed connections with high torques.
- › Ensure that the ball engages properly in the ball catch.
- › Always pull the tool towards you. Never push the tool away from you. If for design reasons you can only press the tool away from you, use your open hand to prevent injuring your knuckles.
- › Only use suitable sockets and connections for the impact driver. Use a safety pin and ring to secure the connection between the socket, extension and machine.
- › When using reducers, the smaller drive's torque always applies.
- › Do not use ratchets as levers or as striking tools.



Pullers

- › Read the operating instructions!
- › Use only original spare parts and accessories for your GEDORE puller. Never use worn, modified or defective spare parts or accessories.
- › Wear goggles and protective clothing when working. For added safety, use the GEDORE safety cover 5.10!
- › Before pulling, ensure that the legs are in contact with the part to be pulled and are firmly tightened so that the spindle operates centrally along the axis of the puller.
- › Attention! When using a puller, forces of up to several tons are generated! Take care to ensure that the puller is correctly positioned and is vertical to the component being pulled.
- › Do not use electric or pneumatic power or percussion drivers.



Pipe bending systems

- Read the operating instructions.
- Never use defective or worn pipe bending systems.
Replace defective or worn parts with original parts.
- Use suitable systems and tools for bending.
- Wear safety goggles, safety shoes and protective clothing.
- Ensure stability of the pipe bending system during the bending process.

Safety notes for striking tools

Chisels

- Wear safety glasses and safety gloves!
- Before starting work, check that the chisel blade is sharp and the striking end is burr-free! The blades must be properly wet-sharpened!
- Select the appropriate type and size of chisel for the work to be carried out!
- Hold the chisel with a firm grip!
- When working, keep your eyes on the chisel tip!
- Wherever possible, use a chisel with hand guard.
- Never use chisels on workpieces harder than 40 HRC!
- Set safety guards in place to prevent splinters and chips posing a hazard for other people!

Centre punches, drifts and mortise chisels

- These tools are subject to the same safety rules as chisels.

Cutting tools

- Always set cutting tools down on a clearly visible place. Handles should always point towards you.
- Sharpen your cutting tools regularly. Blunt cutting tools represent a greater risk of injury than sharp ones. Blunt cutting tools require more force to be applied.
- Store cutting tools separately. This protects the blades and your fingers.
- Set shears down with their tips closed. This protects the blades and your fingers.



Torque tools

- Read the operating instructions.
- Only use correctly calibrated torque wrenches.
- Treat torque wrenches as measuring equipment. Store torque wrenches carefully.
- Only use torque wrenches within the permissible torque range.
- Stop tightening the bolt immediately once you feel and hear the "click" signal.
- Apply the torque wrench at a right angle to the screwed connection.
- Only use original end fittings or accessories which fit the respective torque wrench.
- Where possible, do not use any reducers.
- Never loosen bolts using a torque wrench.
- Never use the torque wrench as a hammer.
- Slacken the torque wrench after completing work.
- Never use defective or worn accessory parts. Replace defective or worn parts with original parts.
- Only use one hand on the handle of the torque wrench; two-handed operation is only possible using DREMOMETER A - F.



Torque Multipliers

- Read the operating instructions!
- Wear safety goggles, safety shoes and protective clothing!
- Always inspect the torque multiplier for damage before use!
- Never use electric, pneumatic or battery-operated torque multipliers or impact wrenches!
- Never exceed the specified maximum input torque!
- Always use impact sockets in accordance with DIN 3129 or ISO 2725-2 and ISO 1174!
- Always securely connect the reaction arm to the support bolt!
- Never extend the impact socket or connector between bolt and torque multiplier!
- Never use a universal or cardan joint!
- Never hit the torque multiplier with a hammer!
- Do not drop the torque multiplier!
- Never use the torque multiplier if it has been dropped, used to strike other objects, or if anything has fallen on it.
- Always keep hands and fingers away from the reaction arm!
- Always select an anchor point (wall, another bolt) sufficient to withstand torque reaction forces! Reaction torque equals output torque.
- Never allow the gearbox to touch a wall or other object!
- Never modify the reaction arm without consulting with the manufacturer!





Safety notes for hammers

- Wear safety glasses and safety gloves!
- Use the hammer only for its intended purpose!
- Never misuse the hammer as a lever!
- Before starting work, check that the hammer head is securely attached to the shaft!
- Select the appropriate type and size of hammer for the work to be carried out!
- Never hit two hammers together!
- Never use steel hammers on workpieces harder than 46 HRC! Use suitable plastic-faced hammers for this! In case of doubt, the healthier choice is a suitable plastic-faced hammer.
- Avoid bouncing blows!
- Use only the work faces of the hammer! Blows with the side face damage the non-hardened hammer eye. This can loosen the grip of the shaft in the hammer head.
- If a burr forms on the pein or face of the hammer head, this must be immediately removed. Failure to do this can pose the risk of splintering when the hammer is in use.
- Grip the hammer shaft as far away from the hammer head as possible! This improves the impact effect and avoids vibrations.
- Do not store hammers with wooden shafts in warm, dry environments! Wood is a natural product. Dry, warm storage conditions cause the shaft to lose moisture and shrink, so that the hammer shaft is no longer a tight fit in the hammer head. Opposite storage conditions also have a negative effect on the wooden shaft. Do not store the wooden shaft in too damp conditions! Too much moisture causes the wooden shaft to swell up and damages the wooden fibres. This can result in the wooden shaft snapping behind the eye area.
- Use only approved non-sparking hammers for work in explosion-hazard areas!
- Use only suitable GEDORE replacement shafts and wedges.



Safety notes

- For engines with ignition coils integrated in the spark-plug connector (coil-on-plug), use only spark-plug sockets with retainer springs! (Nos. 50 - 59)
- Do not use magnetic spark-plug spanners on coil-on-plug spark plugs!
- This can result in control unit faults!



Work gloves

- Read the operating instructions.
- Ensure that your work gloves are suitable for the respective task to be performed. Examine your work gloves for damage before use. Damaged work gloves must be replaced.
- Only work using work gloves which fit your hands perfectly.
- Store your work gloves in a clean and dry place.



Safety goggles

- Read the operating instructions.
- Ensure that your safety goggles are suitable for the respective task to be performed.
- Examine your safety goggles for damage before use. Damaged safety goggles must be replaced.
- Store safety goggles in dry areas. Use the black plastic bag provided for this purpose. This will help you to avoid scratches on the lenses.
- Clean the lenses regularly under running water, not when dry.
- Do not wear safety goggles on top of standard spectacles. Mechanical effects can be transferred which may be dangerous.



Ear protection

- Read the operating instructions.
- Ensure that your ear protection is suitable for the respective task to be performed.
- Examine your ear protection for damage before use. Ear protection displaying damage must be replaced.
- Wear ear protection for the entire duration of your stay in noisy areas.
- Store your ear protection in a clean and dry place.
- Avoid impact against the earpieces. Otherwise, this can lead to a noise level which is harmful for your ears.



Pliers

- Wear protective goggles when working with pliers! Ejected bits of wire and circlips not correctly positioned in the tip of the pliers pose a risk to your eyes!
- Check on the jaws for wear and tear! Worn jaws result in slipping and thus in accidents.
- The joint of the pliers is not to have any noticeable play! Exceptions are the sliding joints.
- When cutting wire, choose pliers that match the wire diameter and wire hardness!
- Never use pliers as hammers!
- Only insulated and tested pliers are to be used when working on electrical equipment!
- Grip wrenches are only for briefly fixing workpieces!

TIGHTENING / TEST TORQUE

Wrench/spanner test torques in accordance with DIN ISO 1711-1 (minimum guaranteed values) N·m							Test torques for tightening tools for hexagon socket head screws								
mm	mm	With internal square as per DIN 3120					DIN EN ISO 4762 mm	No. 42T, DT42 No. 42, 42EL	No. IN 34	With hexagon head as per DIN 7422					
		6,3	10	12,5	20	25				6,3	10	12,5	20	25	
		No. 20 No. D 20	No. 30 No. D 30	No. 19 No. D 19	No. 32 No. D 32	No. D 21				No. IN 20	No. IN 30	No. IN 19	No. IN 32	No. IN 21	
		1/4"	3/8"	1/2"	3/4"	1"					1/4"	3/8"	1/2"	3/4"	1"
M 2	4	10,4					1,5		0,82						
M 2,2	4,5*	12,6					2		1,9		1,9				
M 2,5	5	15,1													
M 3	5,5	17,8					2,5		3,8		3,8				
M 3,5	6*	20,6	23,2												
M 4	7	26,8	33,2				3		6,6	6,6	6,6				
M 5	8	33,6	45,5	94,1			4		16	16	16	16	16		
	9*	41,1	59,9	119,2											
M 6	10	49,1	76,7	147			5		30	30	30	30	30		
M 7	11	57,8	96	178											
	12*	67,0	118	212											
M 8	13	68,6	141	249			6		52	52	52	52	52		
	14*	68,6	169	288			7		80		78		78		
M 10	15		198	331			8		120	120	120	120	120		
	16		225	377											
	17*		225	425			9		165				165		
M 12	18		225	477			10		220	220		220	220		
	19*		225	531											
	20*		225	569			12		370	370			370		
M 14	21		225	569											
	22*		225	569	569										
	23*			569	569										
M 16	24			569	569		14		590	590		590	590		
	25*			569	583										
	26*			569	624										
M 18	27			569	665										
	28*			569	707										
M 20	30			569	795		17		980	980		1000	1000	1000	
M 22	32*			569	888										
	34			569	984										
M 24	36			1084	1677		19		1360	1360		1400	1400	1400	
M 27	41			1353	1910								2100	2100	
M 30	46			1569	2143		22		2110					2700	
M 33	50			1569	2329		24		2750						
M 36	55			1569	2562		27		3910						
M 39	60			1569	2795		30		4000						
M 42	65				2795		32		4000						
M 45	70				2795										
M 48	75				2795		36		4000						
M 52	80				2795										
M 56	85														
M 60	90														
M 64	95														

The matching test torques are derived from the theoretical load capability of the connecting square drive.


Note: Hand tightening sockets are unsuited to use with impact drivers. Inappropriate use poses an accident risk. Power driver sockets can be found on page 230.

HEAD WIDTHS AND THREAD DIAMETERS

Nominal size DIN ISO 272 normal (large) mm	Thread diameter Ø		Nominal size mm	Nominal size		Thread diameter Ø		Nominal size		
	Metric as per DIN ISO 272	Metric for high- tensile bolted structural joints as per EN 14399-4		Inch	mm	mm	BS 916, 1083	Inch	mm	
	Ø mm									
3,2 (-) 4 (-)	1,6 2									
5 (-) 5,5 (-)	2,5 3		5/32	0,1562	3,97	8 BA 7 BA 6 BA		0,152 0,172 0,193	3,86 4,37 4,90	
7 (-) 8 (-)	4 5		7/32 1/4	0,2187 0,2500	5,56 6,35	5 BA 4 BA 1/16 W		0,220 0,248 0,256	5,59 6,30 6,90	
10 (-) 11 (-)	6 7		9/32 5/16	0,2812 0,3125	7,14 7,94	3 BA 3/32 W 2 BA		0,282 0,297 0,324	7,16 7,54 8,23	
13 (-) 16 (-)	8 10		11/32 3/8 13/32	0,3438 0,3750 0,4062	8,73 9,52 10,32	1/8 W 1 BA 0 BA	(3/16) (7/32)	0,340 0,365 0,413	8,64 9,27 10,49	
18 (21) 21 (24) 22	12		7/16	0,4375	11,11	3/16 W	1/4	0,445	11,30	
24 (27) 27 (30)	16 18		16	9/16 19/32 5/8	14,29 15,08 15,88	1/4 W	5/16	0,525	13,34	
30 (34) 32 34 (36)	20		11/16	0,6875	17,46	3/8 W	7/16	0,710	18,03	
36 (41) 41 (46)	24 27		22 24	25/32 13/16 7/8	19,84 20,64 22,22	7/16 W	1/2	0,820	20,83	
46 (50) 50 (55)	30 33		27 30	15/16 1.	0,9375 1,0000	23,81 25,40	1/2 W	9/16	0,920	23,37
55 (60) 60 (65)	36 39		36	1.1/16	1,0625	26,99	9/16 W 5/8 W	5/8 (11/16)	1,010 1,100	25,65 27,94
65 70	42 45			1.1/8 1.3/16 1.1/4	1,1250 1,1875 1,2500	28,58 30,16 31,75	11/16 W	3/4	1,200	30,48
75 80	48 52			1.5/16 1.3/8 1.7/16	1,3125 1,3750 1,4375	33,34 34,92 36,51	3/4 W 13/16 W	7/8 (15/16)	1,300 1,390	33,02 35,31
85 90	56 60			1.1/2 1.5/8 1.11/16	1,5000 1,6250 1,6875	38,10 41,28 42,86	7/8 W 1. W	1. 1.1/8	1,480 1,670	37,59 42,42
95 100	64 68			1.3/4 1.13/16 1.7/8	1,7500 1,8125 1,8750	44,45 46,04 47,62	1.1/8 W	1.1/4	1,860	47,24
105 110	72 76			2. 2.1/16 2.3/16	2,0000 2,0625 2,1875	50,80 52,39 55,56	1.1/4 W	1.3/8	2,050	52,07
115 120	80 85			2.1/4 2.3/8 2.7/16	2,2500 2,3750 2,4375	57,15 60,32 61,91	1.3/8 W 1.1/2 W	1.1/2 1.5/8	2,220 2,410	56,39 61,21
130	90			2.9/16 2.5/8 2.3/4	2,5625 2,3750 2,7500	65,09 66,68 69,85	1.5/8 W 1.3/4 W	1.3/4 2.	2,580 2,760	65,53 70,10
135	95			2.13/16 2.15/16 3	2,8125 2,9375 3,0000	71,44 74,61 76,20	(1.7/8W)			76,70
145	100			3.1/8 3.3/8 3.1/2	3,1250 3,3750 3,5000	79,38 85,72 88,90		2.1/4 2.1/2	3,150 3,550	80,01 90,17
150	105			3.3/4 3.7/8	3,7500 3,8750	95,25 98,42		2.3/4	3,890	98,81
155	110			4.1/8 4.1/4 4.1/2	4,1250 4,2500 4,5000	104,78 107,95 114,30		3.	4,180	106,17
165	115			4.5/8 4.7/8 5.	4,6250 4,8750 5,0000	117,48 123,82 127,00		3.1/4	4,530	115,06
170	120			5.1/4 5.3/8 5.5/8	5,2500 5,3750 5,6250	133,35 136,52 142,88		3.1/2	4,850	123,19
180	125			5.3/4 6. 6.1/8	5,7500 6,0000 6,1250	146,05 152,40 155,58		4.	5,550	140,97
185	130							4.1/2	6,380	162,05
200	140									
210	150									



SPANNER SIZES TOLERANCE FOR BOLTS AND SOCKET WRENCHES

Nominal size / s in mm	Tolerance class 1 as per ISO 691 dimensions		Tolerance class 2 ^a as per ISO 691 dimensions	
				
2 ≤ s < 3	+ 0,02	+ 0,08	+ 0,02	+ 0,12
3 ≤ s < 4	+ 0,02	+ 0,10	+ 0,02	+ 0,14
4 ≤ s < 6	+ 0,02	+ 0,12	+ 0,02	+ 0,16
3 ≤ s < 10	+ 0,03	+ 0,15	+ 0,03	+ 0,19
10 ≤ s < 12	+ 0,04	+ 0,19	+ 0,04	+ 0,24
12 ≤ s < 14	+ 0,04	+ 0,24	+ 0,04	+ 0,30
14 ≤ s < 17	+ 0,05	+ 0,27	+ 0,05	+ 0,35
17 ≤ s < 19	+ 0,05	+ 0,30	+ 0,05	+ 0,40
19 ≤ s < 26	+ 0,06	+ 0,36	+ 0,06	+ 0,46
26 ≤ s < 33	+ 0,08	+ 0,48	+ 0,08	+ 0,58
33 ≤ s < 55	+ 0,10	+ 0,60	+ 0,10	+ 0,70
55 ≤ s < 75	+ 0,12	+ 0,72	+ 0,12	+ 0,92
75 ≤ s < 105	+ 0,15	+ 0,85	+ 0,15	+ 1,15
105 ≤ s < 150	+ 0,20	+ 1,00	+ 0,20	+ 1,40
150 ≤ s < 210	+ 0,25	+ 1,22	-	-

This tolerance class applies only to ring spanners or socket wrenches that have not been manufactured by material removal.

Spanner sizes in accordance with this international standard must be marked with:

- a) Spanner head size
- b) Reference to the international standard, i.e. ISO 691
- c) Nominal size s in millimetres
- d) Tolerance class 1 or 2

Conversion tables Inch to decimal-inches and mm

in.	dec.in.	mm.	in.	dec.in.	mm.
0	0	0	1/2	0.5	12,7000
1/64	0.015625	0,3969	33/64	0.515625	13,0969
1/32	0.03125	0,7938	17/32	0.53125	13,4938
3/64	0.046875	1,1906	35/64	0.546875	13,8906
1/16	0.0625	1,5875	9/16	0.5625	14,2875
5/64	0.078125	1,9844	37/64	0.578125	14,6844
3/32	0.09375	2,3812	19/32	0.59375	15,0812
7/64	0.109375	2,7781	39/64	0.609375	15,4781
1/8	0.125	3,1750	5/8	0.625	15,8750
9/64	0.140625	3,5719	41/64	0.640625	16,2719
5/32	0.15625	3,9688	21/32	0.65625	16,6688
11/64	0.171875	4,3656	43/64	0.671875	17,0656
3/16	0.1875	4,7625	11/16	0.6875	17,4625
13/64	0.203125	5,1594	45/64	0.703125	17,8594
7/32	0.21875	5,5562	23/32	0.71875	18,2562
15/64	0.234375	5,9531	47/64	0.734375	18,6531
1/4	0.25	6,3500	3/4	0.75	19,0500
17/64	0.265625	6,7469	49/64	0.765625	19,4469
9/32	0.28125	7,1438	25/32	0.78125	19,8438
19/64	0.296875	7,5406	51/62	0.796875	20,2406
5/16	0.3125	7,9375	13/16	0.8125	20,6375
21/64	0.328125	8,3344	53/64	0.828125	21,0344
11/32	0.34375	8,7312	27/32	0.84375	21,4312
23/64	0.359375	9,1281	55/64	0.859375	21,8281
3/8	0.375	9,5250	7/8	0.875	22,2250
25/64	0.390625	9,9219	57/64	0.890625	22,6219
13/32	0.40625	10,3188	29/32	0.90625	23,0188
27/64	0.421875	10,7156	59/64	0,921875	23,4156
7/16	0.4375	11,1125	15/16	0,9375	23,8125
29/64	0.453125	11,5094	61/64	0,953125	24,2094
15/32	0.46875	11,9062	31/32	0,96875	24,6062
31/64	0.484375	12,3031	63/64	0,984375	25,0031
			1	1	25,4000

GUIDELINE VALUES FOR THE COEFFICIENT OF FRICTION μ

		Screw thread		Steel			
		Nut thread		blackened or Zinc-phosphate		cadmium-plated	zinc-plated
Steel	ground	Zinc-phosphate 6 μ	pressed rolled	rolled cut	sharpened	6 μ	6 μ
	sharpened		0,14	0,10	0,16	0,10	0,10
	ground sharpened		0,16	0,10	0,16	0,10	0,10
	turned sharpened		0,14	0,10			
	turned sharpened		0,10				
	cadmium-plated		0,10	0,10		0,10	0,10
	zinc-plated					0,14	
	cadmium-plated						0,10
	zinc-plated			0,10			0,14

Choosing the right friction value

In order to exactly define the pre-tension force and the tightening torque, it is essential to know the coefficient friction.

However, it would seem almost impossible to specify definite values for the coefficients of friction for the large variety of possible surface and lubrication conditions and above all for their variance. Added to this are the variances of the various different tightening methods which also constitute a greater or lesser factor of uncertainty. For this reason, it is only possible to make recommendations on the choice of the coefficient of friction. 80 % of the tightening-torque values apply for countersunk head screws on account of the remaining base thickness.

Guideline values for the coefficient of friction μ

In order to exactly define the pre-tension force and the tightening torque, it is essential to know the coefficient of friction. However, it would seem almost impossible to specify definite values for the coefficients of friction for the large variety of possible surface and lubrication conditions and above all for their variance.

The following circumstances influence the friction value:

The surfaces and the nature of the materials being screwed, the method of lubrication, the sliding path due to the flexibility and the tightening method, i.e. the number and the speed of the tightening cycles and finally the tightening path - the so-called hard or soft screw case. The sum total of these items represents a greater or lesser factor of uncertainty. Even DIN-equivalent screws can differ considerably in their friction value because of being delivered by different suppliers, depending on the screw lot and depending on their storage and, in particular, on the oiling or greasing performed in the course of installation. Please note that around 80 to 90% of the tightening torque in most tightening procedures is required for overcoming the friction in the screw.

Important remark:

For this reason, it is only possible to give recommendations on the choice of the friction value. We point out explicitly that the following tables only contain guideline values. In all cases, a detailed screw calculation is more reliable than these tables! That applies particularly for parts which are relevant to safety, are subject to official regulations or perform sealing functions. The tables should only be utilised where the manufacturer of the screws or elements being connected has made no specifications on the required tightening torques.



	Weight (total)		Square drive (external)		Unit Drive hexagon
	Weight (total)		Square drive (external)		Unit Drive bi-hexagon
	Weight hammer head		Square drive (external)		Unit Drive
	Length (total)		Square drive (internal)		Hexagon
	Length (total)		Square drive (internal)		Bi-hexagon
	Length (total)		Square drive (internal)		Internal-TORX®
	Length (total)		Square drive (internal)		Internal TORX® with pilot
	Length of blade		Square drive (internal)		TORX PLUS®
	Length of blade		Square drive (internal)		External TORX®
	Length of shaft / handle		Square drive (internal)		Internal serrations XZN
	Length of point / blade		Hexagon drive (external)		Multi-spline RIBE®
	Diameter (also dia. of head, of shaft, of points)		Hexagon drive (external)		Female three-square
	Diameter		Hexagon drive (external)		TORQ-SET®
	Diameter of hole (external)		Hexagon drive (internal)		Tri-Wing®
	Diameter of hole (internal)		Hexagon drive (internal)		Cutting edge thickness
	Width across flats (Nominal Width)		Hexagon drive (internal)		Jaw width / tape width
	Width across flats (Nominal Width)		Puller		Head width
	Width across flats (Nominal Width)		Clamping spread		VDE Test Symbol (Tool)
	Width across flats (Nominal Width)		Clamping reach		Test Symbol (Protective equipment)
	Width across flats (Nominal Width)		Size of spindle		For working in voltage areas up to 1000 V
	Width across flats (Nominal Width)		Hydraulic spindle		Wire rope
	Width across flats (Nominal Width)		Throat depth		Jaws, angled 45°
	Width across flats (Nominal Width)		Opening capacity		Flat jaws
	Width across flats (Nominal Width)		Drive sections		Flat-round jaws
	Width across flats (Nominal Width)		Slotted		Round jaws
	Thread size, connection thread		Cross-slotted PH		Straight jaws
	Screw dimension (type of thread)		Cruciform PZ		Flat-round jaws
	Ratchet used		Internal square		Round jaws
	Ratchet used		Hexagon internal		
	Ratchet used		Internal hexagon with tamper proof hole		
	Ratchet used		External hexagon		
	Ratchet used		Bi-hexagon external		



Customised for you!

Individual - precise - customised - flexible - right on!



- › Individual product design
- › All RAL colour tints can be produced



- › Foam configurator
- › Bespoke tool modules
- › Two-colour check tool inserts
- › Individual tool set for each insert



- › Extra-size tools
- › Mini batches: Production as of 1 item
- › Special-purpose tools



	Cutting edge with bevel		Drawer		Cylinder lock with folding key
	Cutting edge without bevel		Door		Total brake
	Straight jaws		Shelf		Length/crosswide dividers
	Angled jaws 45°		Pivoting angle		Individual blocking
	Angled jaws 90°		Angle		Thickness of workplate
	Internal retaining rings		Weld-on end fitting		Multi fitting key
	External retaining rings		End fitting with hexagon wrench		Magnetic lifting power
	EPA / ESD, electrostatic discharge		Open end fitting		Stepped key
	Electronic		Flared end fitting		Head height
	File profile flat		Ring end fitting		Head diameter
	File profile three-edged		End fitting with square head		Friction ratchet
	File profile round		Bit holder end fitting		Sliding T bar
	File profile half-round		Ratchet end fitting		Extension
	File profile square		Anti-wind-up-ratchet		Universal joint
	Blade / Cutting edge width		Factory certificate		Driving handle
	Blade thickness		Visual display digital		Adaptor
	Gear ratio		RS 232 interface		Handle
	Output torque (max. N·m)		Bi-directional tightening		Head
	Input torque (max. N·m)		Audible reaction (click)		Dimension shaft
	Scale divisions		Mechanical torque multiplier		Dimension head/striking face
	Single square drive		Integrated electronic hardware		Type of jaw
	Double square drive		DREMOMETER MINI-F operable w/o inaccuracies		POWER PLIERS
	Drive connector		1% Tolerance		Tip diameter
	Spigot-end drive		3% Tolerance		Tip diameter
	in cardboard or plastic packaging		4% Tolerance		Spread range
	in sheet metal box		6% Tolerance		new
	Set in sheet metal or plastic box		Extension with release		Safety symbols
	Head width		Release head		
	Distance, hole to edge		Click Tools		
	GS Seal of tested quality		Slipping Tools		
	magnetic		Breaking Tools		
	Radius		Central locking		
			Cylinder lock		

► Specific surface treatments possible
► e.g. colour anodising and much more



► High-quality forgings based on your requirements
► Special-purpose tools



► Special electronic product programming
► Determining/implementing individual maintenance intervals (calibration/services)

